

NAME

mda-ls – displays basic properties of EPICS MDA files in a directory

SYNOPSIS

mda-ls [-**hvf**] [-**p** *positioner*] [-**d** *detector*] [-**t** *trigger*] [*directory*]

DESCRIPTION

mda-ls is a utility for displaying the basic properties of EPICS MDA files in a directory. By default, the following are shown: name of the file, overall dimensionality of the file, and positioners with their dimensionalities shown. If the file was not completed, the highest dimensionality is represented by the completed number of points, followed by the requested number in parentheses. There is an option for showing the fuller **mda-ls** listing, which shows the time of the beginning of the scan; to see more information about a certain file, use **mda-info**. It is possible to filter listing to those containing the PV for a certain positioner, detector, or trigger.

By default, **mda-ls** displays the properties of files in the current directory, but a different directory can be specified. It doesn't accept file names as arguments.

OPTIONS

- h** Show the help screen.
- v** Show the version information.
- f** Show the fuller listing, which includes the time of the beginning of the scan.
- p** *positioner*
File are selected that use the specified *positioner*.
- d** *detector*
File are selected that use the specified *detector*.
- t** *trigger*
File are selected that use the specified *trigger*.

AUTHOR

Dohn A. Arms

SEE ALSO

mda2ascii(1), **mda-dump(1)**, **mda-info(1)**